

Reporting committee **MEASUREMENT COMMITTEE**
RATING OFFICERS COMMITTEE

WATER BALLAST INPUT

PROPOSAL

If water ballast is input as a volume, then compute weight from the SG of the water. If there is no SG listed then use standard value for sea water.

RATIONALE

A measurer can measure tank volume with a flowmeter, and many manufacturers publish their tank volumes.